



STATIONARY COMPACTORS

**OPERATION, MAINTENANCE,
AND INSTALLATION MANUAL**

FOR
KP-2ST KP-3ST KP-4ST



K-PAC Operator Manual Rev. 9/29/25

1. STANDARD 810/820 OPERATION

INTRODUCTION

THANK YOU FOR PURCHASING A K-PAC STATIONARY COMPACTOR.

The purpose of this manual is to provide the owner and operator with the necessary information to properly and safely install, operate, and maintain your stationary compactor. Also included are sections regarding troubleshooting and service procedures. The manual is not intended as a primary training source, but as a reference guide for authorized, trained personnel. Each person involved in the operation, maintenance and installation of the machine must read and thoroughly understand the instructions in this manual and follow **ALL WARNINGS**.

The employer involved in the operation, maintenance, and installation of the compactor must also read and understand the most current version of the following applicable standards:

ANSI Standard No. Z245.2, "Stationary Compactors Safety Requirements"

A copy of this standard may be obtained from:

ANSI
25 West 43rd Street
New York, NY 10036
OSHA 29 CFR, Part 1910.147

ANY SERVICE OR REPAIRS THAT GO BEYOND THE SCOPE OF THIS MANUAL SHOULD BE PERFORMED BY FACTORY AUTHORIZED PERSONNEL ONLY.

If you should need assistance with your Compacts, please contact your distributor.

When contacting your distributor, you will need to provide:

Compactor Serial Number: _____

Installation Date: _____


**IF YOU HAVE ANY SAFETY CONCERNS WITH EQUIPMENT, OR
NEED FURTHER INFORMATION, PLEASE CONTACT US AT:**

**K-PAC
1302 East Industrial Access Rd
West Point, MS 39773
662-327-4183**

1. STANDARD 810/820 OPERATION

SPECIFICATIONS




KP-2ST STATIONARY COMPACTOR SPECIFICATIONS



1. STANDARD 810/820 OPERATION

SPECIFICATIONS


KP-3ST STATIONARY COMPACTOR SPECIFICATIONS



1. STANDARD 810/820 OPERATION

SPECIFICATIONS

KP-4ST STATIONARY COMPACTOR SPECIFICATIONS



1. STANDARD 810/820 OPERATION

PRE-OPERATION INSTRUCTIONS

FEDERAL REGULATION PROHIBITS THE USE OF THIS EQUIPMENT BY ANYONE UNDER 18 YEARS OF AGE.



STAY CLEAR OF ALL INTERNAL PARTS OF THE COMPACTOR DURING OPERATION. FAILURE TO DO SO COULD RESULT IN SERIOUS INJURY OR DEATH!

NEVER ENTER ANY PART OF THE COMPACTOR UNLESS THE DISCONNECT SWITCH HAS BEEN LOCKED-OUT AND TAGGED-OUT. Use OSHA approved Lock-Out & Tag-Out Process.

Before starting the compactor, be sure no one is inside. Be certain that everyone is clear of all points of operation and pinch point areas before starting.




THE EMPLOYER SHOULD ALLOW ONLY AUTHORIZED AND TRAINED PERSONNEL TO OPERATE THIS COMPACTOR.

This compactor is equipped with a key operated locking system. The key (s) should be in the possession of authorized personnel.

DO NOT REMOVE ACCESS COVERS EXCEPT FOR SERVICING.

Only authorized service personnel should be allowed inside. All access doors on the compactor body should always be secured in place when the unit is operating.

Before operating the compactor, make sure that the ratchets and claws (or chains) are securely attached to the receiver container.



ONLY AUTHORIZED PERSONNEL SHOULD BE ALLOWED INSIDE THE MOTOR CONTROL PANEL. The motor control panel contains high voltage components. See Lock-Out & Tag-Out Instructions in the Maintenance section.

If the compactor is equipped with a security gate or doghouse with security door, **BE SURE THAT THE SECURITY GATE OR DOOR IS CLOSED BEFORE THE COMPACTOR IS STARTED.**


1. STANDARD 810/820 OPERATION

POWER UNIT STANDARD FEATURES

1. A.AB.M810.P7
2. AUTO-OFF-HAND KEY SWITCH (C.AB30.J44)
3. GREEN START PUSH BUTTON (C.AB30.A1)
4. Red Maintain Stop Push Button (C.AB30.FXQ10R)
5. FED./REV. SELECTOR SWITCH (C.AB30.J91)
6. Yellow Low Oil Light (C.CH22.22DS4Y) (Optional)
7. Safety Door Switch Input (if the door is open mid – cycle. Turn the machine on.
The ram will fully retract and shut off the machine)
8. Safe – Stop (ANSI Z245.2-2008 5.7.1 standard requires that after the Emergency Stop is pushed and the machine is turned on. The ram will fully retract and shut off the machine.)
9. Ram stop in the forward (the unit will stop at the end of the forward position)
10. Other options are available please contact the factory.


1. STANDARD 810/820 OPERATION

POWER UNIT SET UP INSTRUCTIONS



1. STANDARD 810/820 OPERATION

POWER UNIT SET UP INSTRUCTIONS



1. STANDARD 810/820 OPERATION

POWER UNIT SET UP INSTRUCTIONS









Connection	Screw Size	Torque Inch-Lb. Min.-Max.
Line Terminals:	No.3	22-31
Load Terminals:	No.3	22-31
Control Terminals:	8	
Aux. Contact:	No.3	8,9-13
Terminal Block:	9	

Note: Main Disconnect/Branch Circuit Protection Must Be Supplied By Customer Refer To Service Installation Manual Fuse And Circuit Breaker Chart.

Note2 Power & Circuit Protection Provided by others Use Copper Conductors Only, 75deg C OR LARGER FOR FIELD CONNECTIONS

Primary Fuse
150VA / 460V = $3260 \times 30\% = 97A$
150VA / 230V = $6521 \times 30\% = 1.55A$
150VA / 26V = $7211 \times 30\% = 2.16A$
Secondary Fuse
150VA / 120V = $1.25 \times 97\% = 2.08A$


OPT/VFD, Activate 1PH Delay to True and use a dual coil valve. When 1PH Delay is on 0-01 can be used for the dual coil.



• Indicates Component Not Covered
In UL Listed Panel Drawing #20AWB


1. STANDARD 810/820 OPERATION

POWER UNIT SET UP INSTRUCTIONS



1. STANDARD 810/820 OPERATION

POWER UNIT SET UP INSTRUCTIONS



1. STANDARD 810/820 OPERATION

FEATURES

1. **Safe Stop Mode:** All of our function modes that are on the HMI, are all set up with Safe – Stop (AnsI Z245.2-2008 5.7.1 standard requires that after the Emergency Stop is pushed and the machine is turned on. The ram will fully retract and shut off the machine. In this mode the machine will look for three things to shut off and clear safe stop (Retract time, Rear limit input activating, or pressure switch reaching 1700Psi for 1second). Once safe stop is cleared out the next time the machine is started up normal operation will accrue.
2. **Start Packer (I-00):** this input activates the start of the machine in Manual Mode. This input also activates Auto mode.
3. **Emergency Stop (I-01):** when this input is not activated the machine will not start up. Also when this input is deactivated and then activated the system will go into Safe Stop. Safe Stop is cleared by start the machine and the cylinder fully retracting and shutting off by the retract time, rear limit input, or pressure switch is activated.
4. **Auto On (I-02):** when this input is activated this allows the system to be activated into Auto Start Mode. Auto mode is either used with a Photo Eye or the Timer Start. To activate Auto mode hold in the Packer Start input for 20 seconds. If the Packer Start input is deactivated the 20 seconds will start all over. The first 5 seconds of activating Auto mode the Auto Alarm output will turn on. At the same time the Auto flashing light output will turn on, the Auto flashing light will flash the entire 20 seconds. Once the 20 seconds has timed out the machine will start up and fully retract and shut off. Depending on what Auto mode is running, once the Auto Start signal is activated the Auto Alarm output will turn on 5 seconds before the machine turns on. The machine can also be start up in Auto mode by pushing the Green Start button.
5. **Manual On (I-03):** when this input is activated this allows the system to run in Manual mode by powering the Packer Start Input.
6. **Manual Reverse (I-04):** this input will only function when it gets momentarily activated and deactivated, and only when motor output and forward output are active. Once the reverse input is activated the direction of the cylinder will go from forward to reverse and the motor output will stay on as well. Once the Rear Limit input activated, pressure transducer in retract (1700psi), or the retract time times out. The machine will shut off, the next time it is started up normal operation will accrue.

1. STANDARD 810/820 OPERATION

FEATURES

7. **Rear Limit Switch (I-05):** when this Rear Limit Switch input is activated, while the motor and reverse coil outputs are activated the cylinder will either shutoff if in Safe Stop, Shift to forward for a complete cycle, or shut the machine down when the cycle is complete and the cylinder stops in the fully retracted position. You still want to set the reverse time.
8. **Forward Limit Switch (I-06):** when this Forward Limit Switch input is activated, while the motor and forward coil outputs are activated. The cylinder will travel forward and activate the forward Limit Switch input and shift form the forward output off to the reverse output on.
9. **Auto Start Sensor (I-07):** This input works when Auto Start is implemented to function. When this input is active it will start the machine up automatically after the safety start up warning happens. If this input is active for 20 straight minutes the Auto Shut Down output will turn on and shut the machine down.
10. **Packer Safety Door Switch (I-08):** when this input is not active the machine will not start up in any mode when the Packer Start input is activated. If the machine is running in any mode and if this Packer Safety Door Switch becomes non active the machine will shut off and go into Safe Stop. If any automatic mode is being used the Packer Safety Door Switch has to be activated to activate any Auto mode. Once Automatic mode is active and if the machine is running and the Packer Safety Door Switch becomes non active while the machine is running, the machine will shut off and Automatic mode will become deactivated. If in Automatic mode and the machine is not running if the Packer Safety Door Switch becomes non active the Automatic mode will not deactivate or if the Automatic Start Sensor activates while the Packer Safety Door Switch is deactivated the machine will not start up until the Packer Safety Door Switch becomes active.
11. **(80% / Advance Warning) (I-09):** After any Safe Stop is cleared out and when the motor and forward output are active. Once pressure reaches 80%PSI and holds for 2 seconds, this will turn on the 80% output which will turn a light on. This light will stay on until the E-stop is pushed in to reset the 80% full or if the 100% output full light is activated the 80% output will turn off.

1. STANDARD 810/820 OPERATION

FEATURES

12. **(100% / Container Full Warning) (I-10):** After any Safe Stop is cleared out and when the motor and forward output are active. Once pressure reaches 1700PSI and holds for 2 seconds, this will turn on the 100% output which will turn a light on and will also shut the main motor off and kick the logic into Safe Stop mode. This will also shut off the 80% output. The 100% output will stay on until the E- Stop is pushed in to reset this light. If the start button is pushed in the ram needs to fully retract and shut off (Safe Stop Mode) and the 100% light can stay on. If the start button is pushed in again the system can run a normal cycle and can run with the 100% full light on. If the system is running forward and the 100%PSI holds again for 2 seconds the same thing happens and the system will shut off again and the 100% light stays on.
13. **Low Oil Float (I-11):** when this Low Oil input is deactivated it will not allow the machine to run in any mode. If this input is deactivated it will also turn on the Low Oil Warning Light output. If this input is activated, once the oil leak is fixed and the tank is filled back up with oil the machine can run normal operation and the Low Oil light will clear out. Also when this Low Oil Input is deactivated, it will also set off the Safe Stop for the next start up after Low Oil has been cleared out.
14. **Motor Starter Out Put (O-00):** This output turns on the Motor Start Coil which turns on the main motor on.
15. **Reverse Coil Out Put (O-01):** This output turns on the Reverse directional valve coil when it is time to reverse the cylinder.
16. **Forward Coil Out Put (O-02):** This output turns on the Forward directional valve coil when it is time
17. **80% flashing light Out Put (O-03):** This output turns on the 80% light when the compactor reaches 80% full. The pressure transducer sensor is what activates this Out Put. This 80% light is reset by pushing the Emergency Stop button and deactivating the Emergency Stop input. Once the Emergency Stop Input is reactivated the 80% light will clear out. 80% light will also shut off if the 100% light is activated.

1. STANDARD 810/820 OPERATION

FEATURES

18. **100% full Solid light Out Put (O-03):** This output turns on the 100% light when the compactor reaches 100% full. The pressure transducer sensor is what activates this Out Put. When this light activates it will also shut the machine down. This 100% light is reset by pushing the Emergency Stop button and deactivating the Emergency Stop input. Once the Emergency Stop Input is reactivated the 100% light will clear out.
19. **Low Oil Solid light (O-04):** This output turns on when the Low Oil Float input is deactivated.
20. **Auto Shut Down Flashing light (O-04):** This output turns on when Auto mode is active and the Auto Start Sensor (I-07) is active for 20 straight minutes or set time. If this happens the machine will shut down and clear out the Auto Start active mode and go into Safe Stop and this Auto Shut Down output will turn on. To reset this output push the Emergency Stop button and pull it back out.
21. **Flashing light for Auto Start Out Put (O-05):** This output turns on when Auto mode is being activated and when Auto mode is activated. Once Auto mode is deactivated for any reason this output will deactivate. If Door counter is used this output will turn on for twenty seconds after the final count has been accomplished and before the machine start up.
22. **Horn for Auto Start (O-06):** This output turns on when Auto mode is being activated and also turns on when Auto mode is active and the Auto Sensor is active, this output will turn on five second before the machine start up. If Door counter is used this output will turn on for twenty seconds after the final count has been accomplished and before the machine start up.

1. STANDARD 810/820 OPERATION

OPERATING INSTRUCTIONS (AUTOMATIC MODE)

1. Place the material to be discarded into the compactor.
NOTE: If you are loading the compactor through a door or gate, close it before starting the compactor
2. Insert the key into the "Auto – Off – Hand" key switch and turn to the "Auto" position.
3. Push in the green start button and hold it "Continuously" for 20seconds.
 - Both the audible and visual star-up alarms will energize
 - After 5 seconds the audible alarm will stop, but the visual alarm will continue for additional 15 seconds (for a total of 20 seconds)
 - After 20 seconds the motor and the retract coil will energize and the ram will fully retract "if by- pass cylinders are used the retract time will time and the motor and retract coil will de- energize" "if pressure cylinders are being used once the ram fully retracts and relief pressure activates the pressure switch to I-07. The motor and retract coil will de-energize shutting off the unit.
 - The light will continue to flash, which is a sign of "Auto Mode Active". What will deactivate Auto Mode is pressing the E-Stop button, breaking the safety switch for the door while the machine is running, Turning the key switch to off or Hand Mode, Container full, Low Oil/High Temp. Shut Down and Auto Shut Down.
 - If the unit runs continuously for 20 minutes the system will activate "Auto Shut Down"
4. When the photo eye is blocked there is a 20 second delay before it activates the motor coil and the forward coil. After 15 seconds the audible alarm will activate. The audible alarm will activate for 5 seconds and the motor and the forward coil will energize.
5. The unit will complete a cycle, if the photo eye is unblocked the system will shut off. If the photo eye continues to stay blocked. The system will continue to run. If the Photo Eye is blocked for 20 min. continuously the Auto Shut Down will activate.

2. MAINTENANCE

TROUBLE-SHOOTING

PROBLEM	POSSIBLE CAUSE	SUGGESTED REMEDY
Motor won't start or makes growling noise	Start switch turned but nothing happens	Check reset button on starter Check wiring to panel Check for defective switch block
	No electrical power to unit	Turn on main disconnect Replace fuses or reset breakers
	No electrical power to control circuit	Check primary and secondary sides of transformer Check for correct voltage, check control fuses
	Thermal overload tripped	Reset. Be sure proper sized overload relays are used and amp setting is correct
	Open motor leads	Check continuity. Clean and tighten
	Very low voltage	Check power source
	Single phased	Check power source (3-Phase)
	Rotor or bearings locked	Check shaft for freeness of rotation
	Contactor coil burned out	Replace contactor coil
Motor runs excessively hot	Blocked ventilation	Clean external and internal ventilation system
	High ambient temperature of 105 Fahrenheit	Provide outside source of cooler air
		Reduce number of cycles per hour
Motor runs noisy	Bad bearings	Disconnect from pump coupling and check. If noise does not stop, replace bearings.
	Bad pump or coupler	Disconnect from coupling and check
Thermal overload relays tripping	Incoming leads to incorrect terminals	Correct lead terminal locations
	Low voltage at motor terminals	Improve power supply and/or increase line size
	Single phasing	Check power source, must have all 3 phases (for 3-Phase models only)
	Excessive voltage drop	Eliminate
	Overload amps set too low	Correct setting per nameplate current on motor
	Incorrect overload for voltage used	Replace per nameplate current on motor
	Loose electrical connections	Clean and retighten

2. MAINTENANCE

TROUBLE-SHOOTING (CTD)

PROBLEM	POSSIBLE CAUSE	SUGGESTED REMEDY
Thermal overload does not trip soon enough	Overload setting to high	Set correctly
	Line voltage too high for motor	Rewire motor and starter. Match to line voltage. Replace overload with correct one or reset if applicable
Excessive vibration (out of balance)	Motor mounting	Check alignment between motor and pump. Be sure motor mounting is tight and solid.
	Pump	Disconnect pump from coupling and restart motor. If vibration stops, the unbalance is in the pump. Replace the pump.
	Coupling	Remove coupling and restart motor. If the vibration stops, the unbalance is in the coupling. Replace spider coupling.
Packer does not develop full packing force	Main relief set to low	Re-adjust.
Motor and pump run, but compactor does not operate	Low oil level	Add oil
	Hoses not properly connected	Check quick coupler connections
	Loading chamber lid or door open	Compactor ram will not run with lid or door open. Close lid or door.
	Incorrect pump motor rotation	Reverse any two motor leads on the starter (3 Phase only)
	Pump suction screen plugged	Clean suction screen
	Key sheared on pump motor shaft	Replace key and any damaged parts. Make sure set screw is tight and Loctite.
Cycle time to long	Restriction or kink in hose	Check hose
	Pump worn or damaged	Replace pump
	Pump suction screen plugged	Clean suction screen
Power unit does not shut off at end of packing cycle	On multicycle units the setting may be incorrect	Readjust counter or timer to desired cycles.
	Return timer setting (T2)	Decrease timer setting (T2)
System operates continuously over main relief and ram does not operate	Main relief set too low	Adjust main relief
	Pressure switch set too high or solenoid stuck in "pack" position	Adjust pressure switch or disassemble and clean solenoid valve
Power unit shuts off before end of cycle	Return timer setting (T2)	Decrease timer setting (T2)

2. MAINTENANCE

TROUBLE-SHOOTING (CTD)

PROBLEM	POSSIBLE CAUSE	SUGGESTED REMEDY
Erratic operation	Valve sticking or binding	Disassemble and clean as necessary
	Viscosity of oil too high	Change oil to factory recommended viscosity
	Air in system	Check for leaks, tighten fittings.
	Low oil	Fill reservoir
	Low voltage	Check primary & secondary sides of transformer for correct voltage
Pump makes noise (sounds like gravel)	Partly clogged intake strainer or restricted intake pipe	Pump must receive intake fluid freely or cavitation results. Flush the system. Clean intake pipe and clean or replace strainer. Add clean fluid
	Defective bearing	Replace pump
	Air leak at pump intake pipe joints	Tighten joints as required
Pump shaft seal leak	Seal worn or damaged	Replace seals or pump
Rapid pump wear	Abrasive matter in hydraulic oil bearing circulated through pump	Install adequate filter or clean
	Viscosity of oil too low	Replace with factory recommended oil
	Pressure to high	Reduce pump pressure to factory specifications
	Air recirculation causing pump noise	Tighten all fittings
Excessive heat	Continuous running	When over 140 or hot in comparison with circuit lines, pump should shut down immediately before restarting, insure the fluid cooling capacity is adequate to remove system generated heat Install cooler oil Install oil temperature shut down switch
	Undersize hydraulic lines added; power unit too far from compactor for hose size	Replace with larger hoses
	High ambient temperature in relation to oil temperature	Use lower viscosity oil
	Excessive system leakage	Check and replace contact block necessary
	Pressure switch setting	Readjust pressure switch. Increase pressure setting.
	Pressure switch setting	Readjust pressure switch. Decrease pressure setting.
Container 80% Full light is on before container is full	Light bulb burned out	Replace bulb
	AVOID THE FOLLOWING: EXCESSIVE GREASING OF MOTOR, MISALIGNMENT OF MOTOR AND PUMP, AND CONTAMINATION ON MOTOR AND ELECTRICAL COMPONENTS.	

2. MAINTENANCE

CHARTS

FUSES AND CIRCUIT BREAKERS

THREE PHASE

MOTOR SIZE	VAC	FULL LOAD AMP.	DUAL ELEMENT FUSE MAX, SIZE	CIRCUIT BREAKER MAX SIZE	SERVICE DISCONNECT AMP.
3 HP	208	8.5	15	20	30
	230	8.2	15	20	30
	460	4.1	10	15	30
	575	3.3	6	15	30
5 HP	208	13.1	30	40	30
	230	11.5	25	40	30
	460	5.7	15	20	30
	575	4.8	10	15	30
10 HP	208	27.5	50	80	60
	230	25.6	50	70	60
	460	12.8	25	35	30
	575	11.4	20	30	30
15 HP	208	47.3	60	90	60
	230	45.0	60	90	60
	460	22.5	30	40	30
	575	18.3	30	40	30
20 HP	208	51.0	100	125	100
	230	48.0	90	125	100
	460	24.0	45	60	60
	575	19.1	35	50	60
30 HP	208	81.0	150	225	200
	230	76.0	150	200	200
	460	38.0	70	100	100
	575	28.6	60	80	60

THREE PHASE

3/4 HP	120	8.2	20	20	30
	230	4.1	10	15	30
3 HP	208	15.5	30	45	30
	230	14.0	25	40	30
5 HP	208	22.0	50	80	60
	230	20.8	45	70	60
10 HP	208	43.0	100	125	100
	230	39.0	90	125	100

2. MAINTENANCE

CHARTS

Wire Size				
<u>THREE PHASE</u> THW Copper 75°C (165°F)				
MOTOR SIZE	Voltage	Length		
		TO 100'	TO 200'	TO 300'
3 HP	208	10	8	6
	230	12	10	8
	460	12	12	12
	575	12	12	12
5 HP	208	10	6	4
	230	10	8	6
	460	12	12	10
	575	12	12	12
10 HP	208	6	4	2
	230	8	4	3
	460	12	10	8
	575	12	12	10
15 HP	208	4	2	1
	230	6	3	2
	460	10	8	6
	575	12	10	8
20 HP	208	4	1	1/0
	230	4	2	1
	460	10	8	6
	575	10	10	8
30 HP	208	2	0	3/0
	230	2	1	2/0
	460	6	6	4
	575	8	8	6
<u>THREE PHASE</u>				
3/4 HP	120	12	8	6
	230	12	12	10
3 HP	208	8	6	4
	230	8	6	4
5 HP	208	8	6	4
	230	8	6	4
10 HP	208	4	1	1/0
	230	4	2	1/0

2. MAINTENANCE

CHARTS

MOTOR STARTERS AND HEATER ELEMENTS

THREE PHASE

MOTOR SIZE	VOLTAGE	STARTER SIZE	HEATER ELEMENT A-B
3 HP	208	1	W-50
	230	1	W-50
	460	1	W-43
	575	1	W-41
5 HP	208	1	W-55
	230	1	W-53
	460	1	W-46
	575	1	W-44
10 HP	208	2	W-63
	230	2	W-62
	460	1	W-55
	575	1	W-53
15 HP	208	3	W-68
	230	2	W-69
	460	2	W-61
	575	2	W-58
20 HP	208	3	W-68
	230	3	W-68
	460	2	W-61
	575	2	W-59
30 HP	208	3	W-75
	230	3	W-74
	460	3	W-65
	575	3	W-62

THREE PHASE

3/4 HP	120	1	W-50
	230	1	W-43
3 HP	208	1	W-57
	230	1	W-56
5 HP	208	2	W-61
	230	2	W-60
10 HP	208	3	W-66
	230	3	W-65

3. INSTALLATION

CONCRETE PAD REQUIREMENTS

CAUTION!

REVIEW THIS MANUAL BEFORE MAKING THE INSTALLATION. STUDY THE JOBSITE AND INSTALLATION REQUIREMENTS CAREFULLY TO BE CERTAIN ALL NECESSARY SAFEGUARDS AND OR SAFETY DEVICES ARE PROVIDED TO PROTECT ALL PERSONNEL AND EQUIPMENT DURING THE INSTALLATION AND AS A COMPLETED SYSTEM. SPECIAL ATTENTION IS DIRECTED TO THE MOST CURRENT EXTRACT FROM AMERICAN NATIONAL STANDARDS Institute Z245.2.

These operating instructions are not intended as a substitute for training and experience in proper use and safety procedures in operating this equipment.

K-PAC does not assume responsibility for the installation procedures of this equipment. Conformance to applicable local, state, and federal laws concerning installation rests with the customer.

CONCRETE PAD

1. Preferred dimensions of the concrete pad are 10'0" wide and a length of 5'0" greater than the length of the compactor/container. It should be level and of minimum 3000 PSI concrete steel reinforced, 6" thick. It is preferred that the concrete pad be flush with the surrounding ground level.


NOTE: Containers with four ground rollers must be installed on a level pad.

2. To provide accessibility, concrete pad should be positioned to allow 2'0" between machine and building wall if installed parallel with building. Allow a minimum of 45' of clear space from end of pad for container handling vehicle.

NOTE: The clearances given are minimums. Your installation may require greater clearances depending on the site and the hauling equipment that will be used.

ANCHORING

The compactor should be anchored to concrete pad using (4) minimum 3/4" x 6" long anchor bolts. These bolts can be secured to concrete pad using "Porok" or special concrete anchors. It is best if these holes are drilled in the concrete after prelocating the compactor in its desired location. Holes in the leg plates are 1-5/16" dia. to permit the use of a 1-1/8" dia. concrete bit. The 1-1/8" dia. holes in the concrete should be approximately 5" deep. When the compactor has been permanently located, shimmed to compensate for unevenness, and anchor bolts set, tighten all nuts securely.



NOTE: ENSURE ANCHOR BOLTS ARE NOT ALLOWED TO TORQUE OR TWIST THE COMPACTOR BODY WHEN TIGHTENED.

3. INSTALLATION

STEEL INSTALLATION PROCEDURES

DOCK INSTALLATION

If the appropriate accessories are ordered from K-PAC the compactor will be furnished with either a four-sided hopper or a three-sided hopper with a hinged gate.

THESE ACCESSORIES SHOULD NOT BE ALTERED AS THEY ARE MANUFACTURED IN ACCORDANCE WITH THOSE STANDARDS WHICH PREVAIL AT THE TIME OF MANUFACTURE.

If the compactor/container cannot be directly abutted to the dock or if there is any difference in height between the dock and the compactor, an appropriately sturdy transition section should be provided by the customer and securely affixed to the dock.

Along with the transition section, a container guidance/stop mechanism should be installed to assure that the container does not damage the compactor during placement.

Optional container guides with stops are available from K-PAC and are recommended for proper dock placement of the compactor / container.

CHUTE-FED INSTALLATION

Compactors installed in this arrangement are normally fed "through-the-wall". The lower edge of the access hole in the wall should be a MINIMUM of 42" (and, if possible, not more than 58") from the inside floor level. A security door (in accordance with local code) should be installed in the wall opening.

In the absence of a local code, this door should be constructed of 3/16" thick steel or of steel hollow core design and be lockable from the inside of the building.

DECALS

Be certain that the appropriate decals are in their proper locations at all times on the machine. For decal locations, see "**DECALS**" and "**DECAL PLACEMENT**" in the operation section of this manual.


CONTAINER GUIDES

If container guides (optional) are used with the compactor and container, each guide should be anchored to the concrete pad using two (2) 3/4" X 6" (minimum) anchor bolts. These bolts should be concrete anchors or expansion type anchor bolts. To allow for construction variations, it is best if these holes are drilled in the concrete after prelocating the container guides in their desired location. When the guides have been placed in position, and the anchor bolts have set, tighten all nuts securely.

3. INSTALLATION

ELECTRICAL & HYDRAULIC INSTALLATION

The panel box contains high voltage components. Only authorized service personnel should be allowed inside. See Lock-Out & Tag-Out instructions in the maintenance



A lockable fused disconnect switch (customer furnished) must be installed and be within sight of the compactor motor control panel location, not to exceed 50'0" from the compactor. This fused disconnect switch should be sized in accordance with the compactor (see Fuse and Circuit Breaker Chart).

DANGER: All equipment must be grounded per National Electric Code.

GROUNDING INSTRUCTIONS

This appliance must be connected to a grounded, metal, permanent wiring system; or an equipment grounding conductor must be run with the circuit conductors and connected to the equipment grounding terminal or lead on the compactor.

If there is any doubt whether the appliance is properly grounded, a qualified electrician should be consulted.

REMOTE POWER PACK INSTALLATION

1. If the power unit is remote, it should be installed and anchored as required by the customer. If push buttons are mounted in the face of the panel box, be certain these controls are located as to be in a convenient, but not hazardous, location to the customer.

CAUTION: Controls must be located so that the Emergency Stop Button is readily accessible to the operator and within three (3) feet of the charging chamber access.

If installation requires the control station to be located in a more remote area, a second Emergency Stop Button should be added and installed in the manner described above.

2. For a through-the-wall power pack installation, see the diagram THROUGH-THE-WALL POWER UNIT INSTALLATION at the end of this manual.
3. Connect the hydraulic hoses between the compactor body and the power unit. The rear port (base end) on the compactor is "A" port. The front port (rod end) on the compactor is "B" port.
4. The limit switch is connected to the power unit with sealite. To install, bolt the limit switch to the pre-drilled hole pattern outside the compactor body (right-hand side towards the rear for compactors with power unit connection on the right-hand side; left-hand side towards the rear for compactors with power unit connection on the lefthand side). Other compactor mounted electrical options are color coded and referenced to the schematic shipped with the compactor. Make sure all wires are connected properly. Check local codes to assure that Sealite is acceptable.

3. INSTALLATION

ELECTRICAL & HYDRAULIC INSTALLATION

PUSHBUTTON CONTROL PANEL

If a remote operator station is furnished, it will be factory wired using Sealtite. If it is necessary to disconnect it from the wires (to install the operator station inside a building), exercise care that these wires are reconnected as originally furnished. (Check local codes to be certain that sealtite is acceptable.)

CAUTION: Operator Station must be located so that the Emergency Stop Button is readily accessible to the operator and within three (3) feet of the charging chamber access door. If installation requires this operator station to be located in a more remote area, a second Emergency Stop Button should be added and installed in the manner described above.

ELECTRICAL CONNECTIONS

- ✓ Run power lines, between fused disconnect switch (customer furnished) and compactor's motor control panel, in accordance with local electrical codes, using knock-outs in bottom of motor control panel. See Fuse & Circuit Breaker Chart for Motors and Wire Size Chart, in the Maintenance Section, to determine the proper service disconnect amperage rating and the proper wire size.

NOTE: High legs should be installed to L3 on motor starter.

- ✓ Check voltage at fused disconnect switch to be certain it is the same as is shown on compactor or remote power pack. If voltage is correct, put fused disconnect switch in "ON" position.

START-UP INSTRUCTIONS

1. With the ram fully retracted, check to be sure the oil reservoir is full to the 3/4 level on the sight gauge (Refer to the maintenance chart for hydraulic oil recommendations). The hydraulic system pressure has been factory set and the entire unit has been operated prior to shipment.

CAUTION: MAKE SURE PERSONS AND MATERIAL ARE CLEAR OF CHARGE BOX AREA.

2. Put fused disconnect switch in "ON" position when ready to start machine. Depress the start button and check the motor fan for proper rotation (should be clockwise).

CAUTION: If the pump rotates backward, stop immediately. The pump will be damaged if it is operated in reverse even for short periods. Reversing any two incoming power lines will change the motor/pump rotation.

3. **Make sure that the operators are trained in the proper use of this equipment.**

3. INSTALLATION

THROUGH-THE-WALL POWER UNIT INSTALLATION

If your installation uses a remote power unit mounted through-the-wall, the following list of material and diagram is the suggested method of arranging the hydraulic plumbing.

List of Material		
Item #	Quantity	Description
1	2	Hydraulic Hose, Hi-Pressure (sized to power unit*), 36" long
2	2	Pipe, Schedule 80 (sized to power unit*), 36" long
3	2	Hydraulic Hose, Hi-Pressure (sized to power unit*), 48" long
4	2	Steel plate with holes for Item # 2, 3/16" x 8" x 12"
5	4	Coupling, Female (sized to fit hose & pipe*)
6	3	Coupling, Male x Female Swivel

* 1/2" for hose lengths of 20'-0" or less. Must be 3/4" for 18.5 gpm or greater. Consult factor for longer lengths.

WARNING: AN EMERGENCY STOP BUTTON MUST BE MOUNTED WITHIN 3'-0" OF THE COMPACTOR CHARGE BOX.

